

Arvin Dosari Company

Scale Model 6700Plus

Wi-Fi Control Software Document

Doc Version	Date	Description
0	Saturday, January 25, 2014	First Issue
1	Tuesday, January 28, 2014	Sending PLU added
Please be aware that the documents may change in the course of this development.		

Table Of Contents

1.	Installation	2
2.	Setup SQL Server Database.....	2
3.	Run Application For First Time	2
4.	Sending PLU	3

1. Installation

Install Arvin Wi-Fi Control by executing **setup.exe**. After installation run application from desktop.

2. Setup SQL Server Database

- 1- Open SQL Server Manager.
- 2- Select active database.
- 3- Open **ReceiptHeader.sql** and **ReceiptDetail.sql** script files and change **Arvin.Service** to your active database name.
- 4- Execute both scripts. Two tables will be added to your database.

3. Run Application For First Time

Open settings from menu, Fill SQL Server and active database name fields.

Enter address of scales in main form.



4. Sending PLU

For sending PLU list to workstation:

- 1- Make sure Arvin Wifi Control is running.
- 2- Open new text file and save as **plu.txt**
- 3- Enter IP addresses and PLU list as like as following format.
- 4- Copy **plu.txt** file to **c:\ArvinData** folder, Application will read plu.txt file and delete it automatically.
- 5- If workstation is available, PLU sending is done.

```
[IP]
192.168.0.100
.
.
.
[DATA]
hotkey, prod_id, name, barcode, price, 0, tax, 0, 0, allow_change_price, unit
.
.
.
[END]
```

Acceptable data for **allow_change_price** is **TRUE** or **FALSE** and for **unit** is **A, W** or **Q**